

ASSEMBLY INSTRUCTIONS DIAGRAM ON BACK

Peel paper off of each part. *Optionally wet paper with warm water to make it easier to peel



3 If you purchased this as an upgrade to the original Rock64 Zebra case discard this piece.



4

Apply heatsinks before installing Rock64.

- 5 Insert screws into Rubber feet before assembly.
- 6 Pla

Place screws through bottom and assemble "bottom-up" as shown on back of card for simplest assembly.

C4LABS.COM

